



Pressure Vs Torque Conversion Chart

Titan LP Series Tools

	LP2	LP4	LP8	LP16	LP32
PUMP PSI Setting	<i>Torque - Ft. Lbs</i>				
1500	268	568	1075	2360	4896
1600	286	606	1146	2518	5222
1800	322	682	1290	2832	5875
2000	360	758	1488	3174	6528
2200	396	833	1637	3491	7181
2400	431	909	1785	3808	7834
2600	467	985	1934	4126	8486
2800	503	1061	2083	4443	9139
3000	541	1136	2289	4820	9792
3200	577	1212	2442	5142	10445
3400	614	1288	2594	5463	11098
3600	650	1364	2747	5784	11750
3800	686	1439	2899	6106	12403
4000	724	1515	3028	6475	13056
4200	760	1591	3180	6799	13709
4400	796	1667	3331	7123	14362
4600	833	1742	3483	7447	15014
4800	869	1818	3634	7770	15667
5000	904	1894	3878	8156	16320
5200	940	1970	4033	8482	16973
5400	976	2045	4188	8808	17626
5600	1013	2121	4343	9134	18278
5800	1049	2197	4498	9460	18931
6000	1087	2273	4704	9789	19584
6200	1123	2348	4859	10116	20237
6400	1159	2424	5017	10442	20890
6600	1196	2500	5174	10768	21542
6800	1232	2576	5331	11095	22195
7000	1271	2652	5545	11504	22848
7200	1307	2727	5704	11833	23501
7400	1343	2803	5862	12162	24154
7600	1380	2879	6021	12490	24806
7800	1416	2955	6179	12819	25459
8000	1459	3030	6364	13046	26112
8200	1496	3106	6523	13372	26765
8400	1532	3182	6682	13698	27418
8600	1568	3258	6841	14024	28070
8800	1605	3333	7000	14350	28723
9000	1640	3409	7163	14700	29376
9200	1676	3485	7322	15027	30029
9400	1713	3561	7481	15353	30682
9600	1749	3636	7641	15680	31334
9800	1785	3712	7800	16007	31987
10000	1826	3788	8024	16231	32640

9001 Jameel Road, Suite 180 • Houston, TX 77040

Toll Free: 866.345.8484 • Phone: 281.449.9994 • Fax: 281.449.9996 • Email: sales@titanti.com