



Pressure Vs Torque Conversion Chart					
<i>Titan T5 Square Drive Tool</i>					
Pressure	<i>Torque</i>		Pressure	<i>Torque</i>	
Psi	<i>Ft-Lb</i>		Bar	<i>Kgm</i>	<i>Nm</i>
1500	816		103	113	1107
1600	871		110	120	1180
1800	979		124	135	1328
2000	1101		138	152	1493
2200	1212		152	167	1643
2400	1322		166	182	1792
2600	1432		179	198	1942
2800	1542		193	213	2091
3000	1656		207	229	2246
3200	1767		221	244	2396
3400	1877		235	259	2546
3600	1988		248	274	2695
3800	2098		262	290	2845
4000	2230		276	308	3023
4200	2341		290	323	3174
4400	2452		304	338	3326
4600	2564		317	354	3477
4800	2675		331	369	3628
5000	2790		345	385	3783
5200	2902		359	400	3935
5400	3013		373	416	4086
5600	3125		386	431	4237
5800	3237		400	447	4389
6000	3353		414	463	4547
6200	3465		428	478	4699
6400	3577		442	494	4850
6600	3689		455	509	5002
6800	3800		469	524	5153
7000	3891		483	537	5276
7200	4002		497	552	5427
7400	4114		511	568	5578
7600	4225		524	583	5729
7800	4336		538	598	5880
8000	4492		552	620	6092
8200	4605		566	635	6244
8400	4717		580	651	6396
8600	4829		593	666	6549
8800	4942		607	682	6701
9000	5056		621	698	6856
9200	5168		635	713	7008
9400	5281		649	729	7160
9600	5393		662	744	7313
9800	5505		676	760	7465
10000	5605		690	774	7601