



Pressure Vs Torque Conversion Chart			
<i>Titan T5 Square Drive Tool</i>			
Pressure	<i>Torque</i>		Pressure
Psi	<i>Ft-Lb</i>		Mpa
			<i>Nm</i>
1500	816		10
1600	870		11
1800	979		12
2000	1104		14
2200	1214		15
2400	1325		17
2600	1435		18
2800	1546		19
3000	1660		21
3200	1771		22
3400	1881		23
3600	1992		25
3800	2103		26
4000	2236		28
4200	2348		29
4400	2460		30
4600	2571		32
4800	2683		33
5000	2808		34
5200	2920		36
5400	3033		37
5600	3145		39
5800	3257		40
6000	3377		41
6200	3490		43
6400	3602		44
6600	3715		46
6800	3827		47
7000	3912		48
7200	4024		50
7400	4136		51
7600	4247		52
7800	4359		54
8000	4532		55
8200	4645		57
8400	4759		58
8600	4872		59
8800	4985		61
9000	5098		62
9200	5211		63
9400	5325		65
9600	5438		66
9800	5551		68
10000	5647		69

9001 Jameel Road, Suite 180 • Houston, TX 77040

Toll Free: 866.345.8484 • Phone: 281.449.9994 • Fax: 281.449.9996 • Email: sales@titanti.com